



# Sony VAIO PCG-3E2L RAM Replacement

The purpose of this guide is to help the reader replace the RAM of the device.

Written By: Chengyang Chen



## INTRODUCTION

This guide will aid readers to replace battery of the device when the RAM is not functioning properly.



### TOOLS:

- [Phillips #00 Screwdriver](#) (1)



### PARTS:


- [4GBPC2-6400\(2GBx2\) RAM](#) (1)

## Step 1 — RAM



- Using a #00 Phillips screwdriver, remove the screw
- Remove the cover


## Step 2



- Use two thumbs to push two plastic around RAM outward.
- Remove the popped up RAM



## Step 3



- Use two thumbs to push two plastic around the other RAM outward.
- Remove the popped up RAM

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-30 04:50:29 AM.